



# IDEXX-SwRI Path Planning Optimization ROS-I Consortium FTP

Chris Lewis
Southwest Research Institute





#### **IDEXX** and SwRI FTP for Path

### **Planning Optimization**



 Movelt! employs OMPL's planners. Although fast, paths are often nonintuitive and sub-optimal

#### FTP Goal:

- Create a path planning capability which provided paths useful to industrial robot tasks.
- Generated paths must be asymptotically optimal (longer computation → paths become more optimal)

#### FTP Tasks:


- Fix a planner bug that short-circuited planning optimization
- Add control to GUI
- Make tuning parameters accessible and explicit
- Make parameter tuning dynamic
- Implement a smoother
- Add documentation for MoveIt! plug-ins





#### Paths Go Out and Around





Video Link







#### Bug

- Planner exited at first valid solution, even when set to try multiple attempts
- Detailed bug description:
  - ompl\_interface::ModelBasedPlanningContext::solve()
  - Incorrectly called
    - ompl\_parallel\_plan\_.solve(ptc, 1, max\_planning\_threads\_, true)
  - The fix: changed to
    - ompl\_parallel\_plan\_.solve(ptc, 1, count, true)
  - Results: Parallel Planner now computes as many as count solutions, combines best segments from all solutions
- Now, the planner runs until either
  - Planning\_attempts\_ is reached
  - Planning\_time\_ runs out






#### Addition to GUI



- Although the move\_group interface allows one to setNumPlanningAttempts(), the GUI did not provide an interface.
- Added a max\_planning\_attempts input





#### **Planner Parameters**



- OMPL provides an interface to a number of different planners.
- Planner parameters are passed from the move\_group interface to the move\_group node then to the OMPL plugin through a generic parameter mechanism as a map.
- Unknown to Most Users:
  - What parameters does this planner have?
  - What is the syntax to set parameters?
  - What do they mean?





#### Ompl\_planner.yaml



- Parameters are already read in from the ompl\_planning.yaml file.
- Just edit, and add a desired parameter and its value to respective configuration.
- Example for DEFAULTRRTStarKConfig:
  - range: 0.05
  - goal\_bias: 0.08







#### Setup Assistant



 Generated ompl\_planning.yaml now includes definitions, default values, and a short description of each of the configurable parameters of the ompl planners.

#### • Results:

- Planning parameter sets are "advertised"
- Syntax is clear
- Parameter meaning is clearer







#### Parameters On the Fly



- All the parameters for each OMPL planner are read from the ROS parameter server on construction. Therefore, one must restart the planning environment to change any of these important values.
- We modified MoveIt! To reload all the parameters every time solve() is called. This allows one to tinker with the parameters using the "rosparam set <parameter\_name> <value> syntax.







#### Important OMPL Parameters



- Range: determines how far, in configuration space, a randomly generated motion can be from an existing part of the path.
  - Large values 
     fast planning with wild motion
  - Small values → slower planning with intricate motion
- Goal\_bias: Determines how often the goal is selected instead of some random point in C-Space.







### Intricate Paths Aren't Smooth



- When the range parameters is small, paths tend to be very choppy near obstacles
- Smoother trajectories desired
- It is also instructive to learn how to write a plugin for Movelt!.
- Wrote a planning adapter plugin for MoveIt! which smoothes the path. May cause collisions, especially for very sparsely generated paths.
- A tutorial was written describing this process


http://wiki.ros.org/action/edit/industrial trajectory filters
/Tutorials/PlanningRequestAdapterTutorial





## Planning Request Adapter Plugin:::ROS industrial


- Planning Request Adapter: add\_smoothing\_filter
- Smoothes trajectory, but is not collision aware





### **Improved Paths**





Video Link







#### Getting the Updates



- Install MoveIt! from source
- Erase all three:
  - Moveit\_setup\_assistant
  - Moveit\_core
  - Moveit\_ros
- New setup assistant
  - Git clone https://github.com/drchrislewis/moveit\_setup\_assistant.git
  - cd moveit\_setup\_assistant
  - git branch fix-84
  - catkin\_make (at top of workspace)
  - Run setup assistant on your urdf.
  - Look at config/ompl\_planning.yaml





#### Getting the Updates



- fir planning request adapter
- GUI updates
  - git clone <a href="https://github.com/drchrislewis/moveit">https://github.com/drchrislewis/moveit</a> ros.git
  - git clone https://github.com/drchrislewis/moveit\_core.git
  - cd moveit\_ros
  - git branch addFirFilter
  - cd moveit\_core
  - git branch FIR\_filter
  - catkin\_make
- Edit launch file to add planning request adapter to planning pipeline if desired
- When running GUI look for new entry field next to planning time called planning attempts.

